

# Code Changing

## 7212 Panel

LCD-Keypad Press Command 55 Then Follow the Instructions on the Display.

LED-Keypad

1. Press Command 55
  2. Then Enter the old Code “1234 “ Then “Ent”
  3. Then Enter the New Code “1786 “ Then “Ent”
  4. Then Enter the New Code again “1786” Then “Ent”
- Your Code is Now Changed*

## Sub Control

1. Make sure the Instant and the Delay Lights are on.
  2. Then Press the “Blank Bar”
  3. Then Enter the Old Code “2258” Then press the “Bar”
  4. Then Enter the New Code “4562” Then press the “Bar”
  5. Then Enter the New Code again “4562” Then the “Bar”
- Your code is Changed but you must wait a Minute before you use the new code it take some time for the control to Change it.*